

DUTY 11 - DISHWASHER AND BAR DISHWASHER

Kitchen Dishwasher - Daily as late in the evening as possible

- Single use gloves are provided in the kitchen areas. Discard after use.
- **Drain:**
 - Remove basket and lift right hand floor panel.
 - Remove overflow pipe (central visible tube) from filter.
 - Close door, select cycle “dr” and press start.
 - Machine will run drain cycle and turn off automatically.
- **Clean:**
 - Remove and carefully clean all the floor filters panels (3).
 - Check that the rinse and wash arms and jets rotate and are free from foreign matter.
 - Wipe exterior of machine with paper towel (don't use detergent mix).
 - Replace filters and overflow pipe.
 - Leave door open if possible to allow machine to air.
 - Check level of detergent and rinse aid in containers in cupboard under kitchen sink and advise Lodge Manager if low.
 - **Disinfect** exterior using the premixed bleach solution in the spray bottles and wipe down with paper towel.

In the Morning

- **Fill:**
 - Run sink tap on hot first until hot water runs from tap (this will reduce dishwasher heat up time).
 - Press on/off button, machine will run self-check then fill and heat water – when ready for use the 3 lights on the left of display will turn green.

Bar Glasswasher - Daily as late in the evening as possible

- Single use gloves are provided in the bar area under the stairs. Discard after use.
- **Drain:**
 - Remove overflow pipe (central visible tube) from filter.
 - Close door, select cycle “dr” and press start.
 - Machine will run drain cycle and turn off automatically.
- **Clean:**
 - Pull up on filter to remove and clean.
 - Check that the rinse and wash arms and jets rotate and are free from foreign matter.
 - Wipe exterior of machine with paper towel (don't use detergent mix).
 - Replace filter and overflow pipe.
 - Leave door open if possible to allow machine to air.
 - Check level of detergent and rinse aid in containers in cupboard under bar sink and advise Lodge Manager if low.
 - **Disinfect** exterior using the premixed bleach solution in the spray bottles and wipe down with paper towel.

In the Morning

- **Fill:**
 - Run sink tap on hot first until hot water runs from tap (this will reduce dishwasher heat up time).
 - Press on/off button, machine will run self-check then fill and heat water – when ready for use the 3 lights on the left of display will turn green.